Shop Name: Dekra MFC Auction House
Tel: --
Email: --
Address: MFC AUCTION HOUSE
M57 PRETORIA ROAD
KEMPTON PARK

Report ID: MAXIA20251009114110
Test Time: 2025-10-09 11:41:10
Technician: Sbu

BMW VEHICLE DIAGNOSTIC REPORT

Vehicle Information

--/BMW/3'/320d_B47/--
VIN: WBA8C56030NV12608
Odometer Reading: 246213km
License Plate: HJ10ZYGP

Customer Information

Name: Dekra MFC AUCTION HOUSE
Tel: 0861033572

Device information

Scanner: MaxiSys MS906 BT
Version: V24.00
Serial Number: VB8GJCC01514
Repair Order Number: --

System Scanned (18)

System	Status/DTC
DDE (Engine-Diesel Electronics)	6
EGS (Electronic Transmission Management)	3
DSC (Dynamic Stability Control)	4
ACSM (Airbag-Advanced Crash Safety Module)	1
KOMBI (Instrument Cluster)	0
FEM (Front Electronic Module)	5
ZGM (Central Gateway Module)	2
ICM (Integrated Chassis Management)	4
EPS (Electric Power Steering)	2
FLEL (Frontal Light Electronics Left) ADAS	0
FLER (Frontal Light Electronics Right) ADAS	0
FZD (Roof Function Center)	1
GWS (Gear Selector Switch)	1
TCB (Combox Emergency Call)	1
HUB (Headunit Basis)	3
CON (Controller)	0
REM (Rear Electronic Module)	3
IHKA (Integrated Automatic Heating And A/C System)	1

DTC (37)

DDE (Engine-Diesel Electronics) (6 DTCs)

DTC	Description	Status
CD94BB	Signal (speed sensor, 46.1.2) invalid, transmitter DSC	Intermittent
CD94F0	Signal (speed sensor, 46.1.2) invalid, transmitter DSC	Intermittent
288F00	Power management: Reduction or switching-off of individual electrical consumers	Permanent
288B00	Power management: Standby current violation	Intermittent
288C00	Power management: Total discharge	Intermittent
2E0600	Engine start, plausibility: Fuel pre-supply pressure too low at engine start	Intermittent

EGS (Electronic Transmission Management) (3 DTCs)

DTC	Description	Status
420511	ETC voltage supply: voltage too low (7 to 9 V)	Intermittent
CF2F02	Signal (actual wheel speed rear left/front left/rear right/front right) invalid, transmitter DSC	Intermittent
CF2DE1	Signal (engine warm-up switch status) invalid, transmitter DME / DDE	Intermittent

DSC (Dynamic Stability Control) (4 DTCs)

DTC	Description	Status
4809B7	Wheel speed sensor: Increment wheel, pulse, rear left	Intermittent
480AAD	Wheel speed sensor: Plausibility, signal fault, rear left	Intermittent
4809AB	DSC: Undervoltage in vehicle	Intermittent
480A90	DSC: Roller brake tester mode active	Intermittent

ACSM (Airbag-Advanced Crash Safety Module) (1 DTC)

DTC	Description	Status
930AA1	Crash safety module: Undervoltage	Intermittent

FEM (Front Electronic Module) (5 DTCs)

DTC	Description	Status
80402F	Power management, battery condition: Total discharge	Permanent
8040B7	De-activation of terminal 15: Top startability limit reached	Intermittent
8040B9	De-activation of terminal 30B: Top startability limit reached	Intermittent
8040BD	Reset or deactivation of terminal 30F	Intermittent
80444D	Inside mirror: Undervoltage detected	Permanent

ZGM (Central Gateway Module) (2 DTCs)

DTC	Description	Status
CD0487	ZGM: Synchronisation process for FlexRay failed	Intermittent

801C20	ZGM: central fault memory full - no control-unit fault	Permanent

ICM (Integrated Chassis Management) (4 DTCs)

DTC	Description	Status
48002C	ICM, ACC: Interface DSC	Intermittent
D017A3	Signal (actual number, signal edge, wheel, 64.1.2) invalid, transmitter DSC	Intermittent
D017C5	Interface DSC (actual speed, wheel, 46.0.1): Signal invalid	Intermittent
D0157A	Signal (wheel torque powertrain 4, 40.3.4) invalid, transmitter DME / DDE	Intermittent

EPS (Electric Power Steering) (2 DTCs)

DTC	Description	Status
4823FC	EPS voltage supply: Undervoltage at the control unit, reduction of steering servo	Intermittent
4823FD	EPS voltage supply: Undervoltage at the control unit, deactivation of the steering servo	Intermittent

FZD (Roof Function Center) (1 DTC)

DTC	Description	Status
801A38	FZD: Undervoltage detected	Intermittent

GWS (Gear Selector Switch) (1 DTC)

DTC	Description	Status
802680	Function indicator defective	Permanent

TCB (Combox Emergency Call) (1 DTC)

DTC	Description	Status
031785	TCB: Functional limitation of breakdown call	Permanent

HUB (Headunit Basis) (3 DTCs)

DTC	Description	Status
B7F86B	HU-B: Undervoltage	Intermittent
026323	HU-B: internal control unit fault (flash memory)	Intermittent
E1C440	HU-B: Reset	Intermittent

REM (Rear Electronic Module) (3 DTCs)

DTC	Description	Status
8031D9	REM: Supply voltage too low	Intermittent
804890	Turn signal plausibility check failed: Function deactivated	Intermittent
E58468	REM, body CAN2: communication fault	Intermittent

IHKA (Integrated Automatic Heating And A/C System) (1 DTC)

DTC	Description	Status

8011FA	Electric auxiliary heater (low voltage): Undervoltage or overvoltage detected	Intermittent

Technician Notes

2017036724

Customer name: _____

Technician: _____

Date: _____

Note:Please save a copy of this report for your records.

Disclaimer: This report provides a reference for vehicle inspection and maintenance only. Autel is not liable for any accident, property damage, or personal injury resulting from the use of this information.