

VOLVO VEHICLE DIAGNOSTIC REPORT

Vehicle Information

--/VOLVO/S60 (11-)/--
VIN: YV1FS41C0G2400123

Odometer Reading: 167699km
License Plate: KW08TYGP

Customer Information

Name: MFC Dekra Nedbank Auction House

Tel: 0861033572

Device information

Scanner: MaxiSys MS906 BT
Version: V17.50

Serial Number: VB8GJCC01509
Repair Order Number: --

 System Scanned(17)

System	Status/DTC
CEM (Central Electronic Module)	 21
ECM (Engine Control Module)	 5
TCM (Transmission Control Module)	 2
ABS/BCM (Anti-lock Brake System Module)	 1
SRS (Supplemental Restraint System Module)	 2
DIM (Driver Information Module)	 0
PBM (Parking Brake Module)	 14
SAS (Steering Angle Sensor Module)	 0
DDM (Driver Door Module)	 0
PDM (Passenger Door Module)	 0
CCM (Climate Control Module)	 1
ICM (Infotainment Control Module)	 3
PSM (Power Seat Module)	 4
PSCM (Power Steering Control Module)	 3
CVM (Closing Velocity Module)	  1
AUD (Audio Module)	 0
PAM (Parking Assistance Module)	  0

 DTC (57)

CEM (Central Electronic Module) (21 DTCs)

DTC	Description	Status
-----	-------------	--------

B102649	Steering column lock, System internal faults, Internal electronic fault	Intermittent Fault
B103C04	Left headlamp control, General fault information, System internal faults	
B104322	Front axle sensor, General signal faults, Signal too high	
B104422	Rear axle sensor, General signal faults, Signal too high	
B10A202	Crash input, General fault information, General signal fault	Intermittent Fault
B10A206	Crash input, General fault information, Algorithm based faults	Intermittent Fault
B10A215	Crash input, General electrical faults, Circuit open/short to battery	Intermittent Fault
B10AC87	Cruise Control (CC) switch, Bus signal/message faults, Message missing	Intermittent Fault
B10AC95	Cruise Control (CC) switch, Component faults, Assembly incorrect	Intermittent Fault
B10AD02	Rain sensor, General fault information, General signal fault	
B110877	Driver door central locking motor, Mechanical faults, Commanded position unreachable	Intermittent Fault
B110977	Passenger door central locking motor, Mechanical faults, Commanded position unreachable	Intermittent Fault
B110A77	Rear door central locking motor (driver side), Mechanical faults, Commanded position unreachable	Intermittent Fault
B110B77	Rear door central locking motor (passenger side), Mechanical faults, Commanded position unreachable	Intermittent Fault
B112B07	Steering Wheel Module, General fault information, Mechanical faults	Intermittent Fault
B11D487	Low speed collision mitigation by braking disabled, Bus signal/message faults, Message missing	Intermittent Fault
B11DB87	Battery monitoring module, Bus signal/message faults, Message missing	Intermittent Fault
B1D1787	Battery backed sounder, Bus signal/message faults, Message missing	Intermittent Fault
U030100	Software incompatibility with ECM/PCM, General fault information, No sub-type information	Intermittent Fault
U040086	Invalid data received, Bus signal/message faults, Signal invalid	
U300316	Battery voltage, General electrical faults, Circuit voltage below threshold	Intermittent Fault

ECM (Engine Control Module) (5 DTCs)

DTC	Description	Status
P250F68	Engine oil level too low, Algorithm based faults, Event information	
P030200	Cylinder 2 misfire detected, General fault information, No sub-type information	
P030400	Cylinder 4 misfire detected, General fault information, No sub-type information	
P030000	Random misfire detected, General fault information, No sub-type information	
P008A00	Low Pressure Fuel System (LPFS) pressure - too low, General fault information, No sub-type information	

TCM (Transmission Control Module) (2 DTCs)

DTC	Description	Status
U030000	Internal control module software incompatibility, General fault information, No sub-type information	
U210000	Initial configuration uncompleted, General fault information, No sub-type information	

ABS/BCM (Anti-lock Brake System Module) (1 DTC)

DTC	Description	Status
C007768	Low tire pressure, Algorithm based faults, Event information	

SRS (Supplemental Restraint System Module) (2 DTCs)

DTC	Description	Status
U300616	Control module input power 'A', General electrical faults, Circuit voltage below threshold	
U300716	Control module input power 'B', General electrical faults, Circuit voltage below threshold	

PBM (Parking Brake Module) (14 DTCs)

DTC	Description	Status
P061E67	Internal control module brake signal performance, Algorithm based faults, Signal fault after event	Intermittent Fault
C200595	Right actuator, Component faults, Assembly incorrect	Intermittent Fault
C200712	Right motor, General electrical faults, Circuit short to battery	Intermittent Fault
C200713	Right motor, General electrical faults, Circuit open	Intermittent Fault
C200812	Left motor, General electrical faults, Circuit short to battery	Intermittent Fault
C200813	Left motor, General electrical faults, Circuit open	Intermittent Fault

U012100	Lost communication with Brake Control Module (BCM), General fault information, No sub-type information	Permanent Fault
U014000	Lost communication with Central Electronic Module (CEM), General fault information, No sub-type information	Intermittent Fault
U042268	Invalid data received from Central Electronic Module (CEM), Algorithm based faults, Event information	Intermittent Fault
U200262	Switch, Algorithm based faults, Signal compare fault	Intermittent Fault
U200264	Switch, Algorithm based faults, Signal plausibility fault	Permanent Fault
U200292	Switch, Component faults, Performance/operation fault	Intermittent Fault
U300000	Control module, General fault information, No sub-type information	Intermittent Fault
U300013	Control module, General electrical faults, Circuit open	Intermittent Fault

CCM (Climate Control Module) (1 DTC)

DTC	Description	Status
U200223	Switch, General signal faults, Signal stuck low	Intermittent Fault

ICM (Infotainment Control Module) (3 DTCs)

DTC	Description	Status
B130013	Video output center console display, General electrical faults, Circuit open	
B13008F	Video output center console display, Bus signal/message faults, Erratic	
U200562	Vehicle speed, Algorithm based faults, Signal compare fault	

PSM (Power Seat Module) (4 DTCs)

DTC	Description	Status
B1C0224	Memory store switch, General signal faults, Signal stuck high	Intermittent Fault
B1C0324	Memory 1 switch, General signal faults, Signal stuck high	Intermittent Fault
B1C0424	Memory 2 switch, General signal faults, Signal stuck high	Intermittent Fault
B1C0524	Memory 3 switch, General signal faults, Signal stuck high	Intermittent Fault

PSCM (Power Steering Control Module) (3 DTCs)

DTC	Description	Status
U014000	Lost communication with central electronic module (CEM), General fault information, No sub-type information	
U042862	Invalid data received from Steering Angle Sensor (SAS) module, Algorithm based faults, Signal compare fault	

U300316 Battery voltage, General electrical faults, Circuit voltage
below threshold

CVM (Closing Velocity Module) (1 DTC)

DTC	Description	Status
U040168	Invalid data received from ECM, Algorithm based faults, Event information	

Technician Notes
2016943873

Customer name: _____

Technician: _____

Date: _____

Note:Please save a copy of this report for your records.

Disclaimer: This report provides a reference for vehicle inspection and maintenance only. Autel is not liable for any accident, property damage, or personal injury resulting from the use of this information.